

TOWCASTERS

The easy way to move ISO freight containers without expensive equipment

Towcasters move ISO freight containers quickly and easily without using expensive equipment such as cranes, gantries, or side-loading forks. The complete system includes four casters featuring adapter plates that lock positively (via quick-action securing screws) into the corner castings incorporated into all ISO freight containers. The locking screws are standard along with a lifting handle and ratchet spanner.

- Economize storage space allows containers to be maneuvered and parked away from the lifting facility
- Ideal, low-cost solution for container manufacture, repairing and marshalling for loading and unloading
- Designed for power towing up to 5 mph suitable for empty or evenly loaded containers up to 40-ft. in length
- No protruding parts so containers can be positioned close together without damage
- Rugged polyurethane-on-cast-iron wheels in 10" and 12" diameters
- Available in sets of two swivel and two fixed casters, or four swivel casters with two directional locks to convert swivel casters into fixed casters
- Easy to install casters can be fitted by one person
- Optional Towbar enables towing by tractor, fork truck or other vehicle







The Revvo Caster Company, Inc.

"Moving in the right direction"



Towcaster Sets #1 & #2 include two swivel and two fixed casters. Towcaster Sets #3 & #4 feature four swivel casters, two with directional locks.


Complete sets also include locking screws, lifting handle, ratchet spanner, and optional Towbar. These accessories are also available as spare parts.



Towbars

The patented Towbar (sold optionally in sets of two) enables towing by tractor, fork truck or other towing vehicle. It measures 8 feet long and fits securely into the ISO container corner brackets immediately above the swivel Towcasters. The Towbars attach to the towing vehicle using standard link pins up to 1-1/2" diameter (not supplied).

Easy to Install



1. Raise container



2. Attach handle and lift caster



3. Insert into corner bracket



4. Square caster and insert locking screw



5. Tighten locking screw using ratchet spanner



6. Remove lifting handle



7. Insert Towbars



8. Ready to tow

Towcaster	Casters	Wheel Diameter	Tread Width	Mounting Height	Load Capacity	Wheel Type	Part #
SET #1	2 Swivel/2 Fixed	10"	3"	15-3/4"	22,000 lbs.	Polyurethane on Cast Iron	ISO-210SUTM
SET #2	2 Swivel/2 Fixed	12"	4"	17-7/8"	26,400 lbs.	Polyurethane on Cast Iron	ISO-312SUTM
SET #3	4 Swivel*	10"	3"	15-3/4"	22,000 lbs.	Polyurethane on Cast Iron	ISO-210SUTM-4S-2DL
SET #4	4 Swivel*	12"	4"	17-7/8"	26,400 lbs.	Polyurethane on Cast Iron	ISO-312SUTM-4S-2DL

^{*} Includes Two (2) Casters with Directional Locks to convert Swivel Casters into Fixed Casters.



The Revvo Caster Company, Inc. 2420 North America Drive • West Seneca, NY 14224 Phone: 716-675-9609 • Fax: 716-677-2363

Toll-Free: 1-888-883-3596

 $\hbox{E-Mail: info@revvocaster.com} \bullet \hbox{www.RevvoCaster.com}$